


Udedele AWHPR 4, 6 og 8 kW R32



Pos.	Varenr.	Betegnelse	Sliddel
1	*	Toppanel AWHPR	-
2	*	Fordamper AWHPR	-
3	095886	Blæsemotor AWHPR	-
4	095887	Blæservinge AWHPR	-
5	095888	Møtrik - blæservinge	-
6	*	Plasthåndtag	-
7	*	Frontpanel AWHPR	-
8	*	Frontgitter + tagrende AWHPR	-
9	*	Bundramme AWHPR	-
10	095889	Vibrationdæmpere - kompressor	-
11	095890	Kompressor AWHPR 4	-
12	095891	Kompressor AWHPR 6+8	-
13	*	Stophanesæt	-
14	095892	Ekspansionsventil AWHPR	-
15	095893	Ekspansionsventilspole AWHPR	-
16	095894	21S4 magnetventilspole	-
17	095895	4-vejs ventil AWHPR	-
18	*	Dækpanel for stophaner	-
19	*	Dækpanel spændingstilslutning	-
20	*	Højre sidepanel AWHPR	-
21	095896	RT65 udetemperatursensor	-
22	095897	RT61-RT62-RT68 temperatursensorer	-
23	*	Terminalblok TB1	-
24	*	Terminalblok TB2	-
25	095898	PC inverter 40 AWHPR 4	-
26	095899	PC inverter 60 AWHPR 6	-
27	095902	PV inverter 80 AWHPR 8	-
28	095903	Sensor L	-
29	*	Baggitter AWHPR	-
30	*	Blæsemotorbeslag	-
31	*	Skillevæg AWHPR	-

920279

